Aim: To show the inverse square distance dependence of the electrostatic force between point

charges.

Subjects: 5A20 (Coulomb's Law)

Diagram:



Equipment:


- 2 Grahite-coated ping-pong balls, hanging from a pair of one meter long threads
- Support (see Diagram)
- Van de Graaff generator
- Lamp, for shadow projection
- Tape



Presentation: The balls are hanging and touch each other. The shadow of the ping-pong balls is projected on the blackboard.

By means of the Van de Graaff generator the two balls are charged and immediately they separate by electrostatic repulsion. While the shadows of the two balls are dancing around towards their equilibrium, the method of the demonstration is explained to the students and to them it is shown that when we suppose the power in Coulomb's law (1785) is really -2, the determined distance-ratio should be $2^{1/3}$ =0.7937 (see Explanation). When the two balls have come to rest, the centers of the shadows of the balls are chalk-marked on the blackboard.

Now the two threads are sandwiched at the halfway point by means of a sliding piece of tape. (This tape is fixed to the threads already before you start the experiment; see Figure.1.)



Clearly can be seen that the two shadows are closer to each other now. Again the centers of the ball-shadows are chalk-marked.

On the blackboard the two seperations are measured. (In a trial, we measured 78- and 62 cm respectively.) The ratio is calculated (62/78=0.7948). This value is very close to the value 0.7937 mentioned before and so the power in Coulomb's law (-2) is supported by this demonstration.

This demonstration gives the opportunity to stress to the students that Coulomb's law is empirical and in that way very fundamental to the theory of electromagnetism. That's why it is very fundamental that measurements around Coulomb's law are still performed, trying to determine n with increasing accuracy (nowadays -1971- it stands to be accurate to 1 part in 10^{16}).

Explanation: Fig.2 shows that in the equilibrium position: $F_{Coulomb}$ = $mg tan \phi$.

Since
$$tan\phi = r/2y$$
, $F_{Coulomb} = \frac{mgr}{2y}$

Supposing
$$F_{Coulomb}=k\,rac{q^2}{r^n}$$
, our equilibrium equation is $rac{kq^2}{r^n}=rac{mgr}{2\,y}$.



k, q, m, and g are constants, so $\frac{y}{r^{n+1}}$ has a constant value.

The first measurement gives us $\frac{y_1}{r_1^{n+1}}$, the second $\frac{y_2}{r_2^{n+1}}$. So, $\frac{y_1}{r_1^{n+1}} = \frac{y_2}{r_2^{n+1}}$.

Since in our demonstration $y_1 = 2y_2$, we find $\frac{r_2^{n+1}}{r_1^{n+1}} \left(= \frac{y_2}{y_1} \right) = \frac{1}{2}$.

The measured r_1 - and r_2 -value gives us n. [We measured, on the blackboard, r_1 =78cm and r_2 =62cm. This makes n=2,0(2).]




Figure 2

Remarks:

- Measuring r_1 and r_2 must be done with some care. For instance when you measure r_2 being 63cm in stead of 62cm you find n=2,2(5) in stead of n=2,0(2).
- When charge leaks away during the demonstration the measured r_2 will be too

 r_1

low making $\frac{r_2}{r_2}$ higher and so n will appear as a higher value. (So usually this will happen.)

 At 3/4 from the upper side of the support a horizontal bar is placed (see Diagram). This makes that when the balls move when they deflect, they remain in the same vertical plane. Without this bar the balls will start to rotate, making a useful shadowprojection impossible. Nowadays we use thin thread instead of a metal bar; a metal bar that close to the balls disturbs the E-field more than a thin thread.

Sources:

- Ehrlich, R., Why Toast Lands Jelly-Side Down: Zen and the Art of Physics Demonstrations, pag. 146-147
- Mansfield, M and O'Sullivan, C., Understanding physics, pag. 443 and 467
- Young, H.D. and Freeman, R.A., University Physics, pag. 674-679
- <u>Buijze W. en Roest R., Inleiding electriciteit en Magnetisme</u>, pag. 11, eerste zin.
- Giancoli, D.G., Physics for scientists and engineers with modern physics, pag. 549-551 and 586!



